



SERVICE INSTRUCTIONS

1-800-KEATING • keatingofchicago.com

FIELD REPLACEMENT OF MG HOTPLATE HEATING ELEMENTS - Part# 059920

Kit Includes:

ITEM	PART #	QTY	DESCRIPTION
A	059502	3	FLAT WASHER, #10 x 7/16" DD
B	005458	3	LOCKWASHER, #10 SPLIT RING
C	015161	3	SCREW, 10-24 x 3/8" SLT PAN HD
D	059919	1	HEATING ELEMENT MG 277V 2600W

Instructions:

1. Shut off all power to the MG Hotplate at the service breaker panel BEFORE performing any service work.
2. Disconnect the MG Hotplate from all electrical power.
3. Make sure that heating elements are cool before handling.
4. To replace a heating element, lift the element from its trim ring and drip pan - pull up and away from the slot in the drip pan to expose the wire connections.
5. Remove the existing element.
6. For each new heating element, attach GRN wire to the "Ground" connection on the heating element spacer flange.
7. Attach BLK (or RED) wire and one end of BLK (or RED) jumper wire to Terminal 2.
8. Attach other end of BLK (or RED) jumper wire to Terminal 1.
9. Attach WHT wire to Terminal 3.
10. Check all connections to be tight.
11. Re-insert the new heating element into the trim ring and drip pan. Make sure heating element, trim ring, and drip pan are aligned and are seated properly.
12. Re-connect power and confirm heating elements are functioning properly.

